



Road Ready Portable Stands


**STANDS ARE RATED AT THE FOLLOWING
MAXIMUM LOAD CAPACITIES**

RRSTANDT	2,200LBS (1000KG)
RRSTANDT1	2,200LBS (1000KG)
RR21STAND	3,300LBS (1500KG)
RRSP	1,100LBS (500KG)

This guide is designed for the following products: **RRSTANDT, RRSTANDT1, RR21STAND, RRSP**


To set up your stand, follow these directions:

- 1.) Remove the carry strap. Unroll the table top and extract the riser.
- 2.) Open the riser to its fully extended position.



- 3.) Place fully open table top onto the riser lining up the riser posts with their respective quick release locking mechanisms.
- 4.) Swing the quick release locking mechanisms into place to secure the riser to the table surface.

Disassembly is reverse of setup.



Important Safety Instructions:

- 1.) Assemble and use on flat surfaces only
- 2.) Do not exceed the maximum load capacity